

MR601 Wiring For Road Vehicle

MR601 configuration #4 sets the F and P outputs for radio vehicle use: steering servo on P1/ch2, indicator/hazard LEDs on P2 and P3, brake LED on F1 and reverse LED on F2. LEDs on P2/P3 are wired from Pn to negative; LEDs on F1/F2 are wired from Fn to battery positive. All must have a series resistor appropriate for the working voltage: 3.3V for P2/P3 and battery voltage for F1/F2.

